



LED Mini Wallpack Light INSTALLATION INSTRUCTION


WARNING

1. To avoid electric shock, disconnect power at source prior to installation.
2. The installation should be performed by qualified electricians or lighting technicians.
3. Before conducting any installation, maintenance, or removal, disable all power to the luminaires and wait until the fixture has cooled down.
4. Do not touch the fixture while it is in use.
5. If there is any problem with fixture, DO turn off the power and DO NOT attempt to repair unless you are a qualified electrician.
6. The electrical rating of this product contains a photocell which is 110-277VAC.
7. Mounting instructions specify the use of a sealing compound to fully fill the gap of the fixture and mounting surface.
8. Wall mount only .


Part No.	Input Voltage	Frequency	Power	Color Temperature	Rated Current(max)
AN-WP26W-345K	110-277V AC	50/60Hz	26W	3000K/4000K/5000K	0.24A

Installation


Mounting with J-BOX



1. To loose the 6 screws on the back cover of the fixture to open the back cover, adjust the CCT.




2. Fix the back cover with fixture by using 6 screws.




LINE	□	BLACK
COMMON	□	WHITE
GROUND	□	GREEN
DIM+	□	PURPLE
DIM-	□	PINK

3. Make supply wire (power and dimming) to fixture wire connections as required thru splice access.


Universal voltage driver permits operation at 110V thru 277V, 50 or 60 Hz. 0-10V control wires must be rated for 300V minimum. For 0-10V Dimming, follow the wiring directions as shown in figure below.




4. Install the bracket on the junction-box with 2 screws.



5. Use 2 Screws to fix bracket after adjusting the position of it.



6. Attach the fixture to the bracket by 2 self screws and washer. then put it flat on the wall.



7. After the fixture is installed on the wall, fill the gap between the wall and the fixture with glue. (Only 3 mounting surfaces need to be filled, another surface don't need to be filled)