




LED Bollard Light INSTALLATION INSTRUCTION

IMPORTANT SAFEGUARDS

When using electrical equipment, basic safety precautions should always be followed including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

1. To reduce the risk of electrical shock, turn off power supply before installation or servicing.
2. This luminaire must be installed in accordance with the NEC or your local electrical code. If you are not familiar with these codes and requirements, consult a qualified electrician.
3. Risk of fire or electric shock. Install this kit only in the luminaires that have the construction features and dimensions shown in the photographs and/or drawings.
4. To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
5. DO NOT install in unstable, loose or easily breakable surfaces.
6. The light source should only be replaced by the manufacturer service technician commissioned by the manufacturer or a person with comparable qualifications.



Model	Input Voltage	Frequency	Power	CCT	Lamp shell	Rated Current(max)	Lumen Output
A-B10/18/25W-345K-BZ	110-277V	50/60HZ	10W/18W /25W	3000K/4000K/5000K	Brown	600mA	611/1088/1662 lm
A-B10/18/25W-345K-BK	110-277V	50/60HZ	10W/18W /25W	3000K/4000K/5000K	Black	600mA	611/1088/1662 lm

NEW CONSTRUCTION INSTALLATION

